

ACCESSORIES

2024/2025



GAGGENAU



From cooktop to Teppan Yaki. With these unique Gaggenau accessories, available in two different sizes, induction cooktops can easily be converted into a Teppan Yaki. Inspired by Japanese cuisine, "teppanyaki" style cooking is a healthy and exciting way to prepare a delicious meal.



Traditional baking just like in a professional brick oven. The Gaggenau baking stone fits in all Gaggenau ovens and can be used to perfectly prepare Tarte flambée, pizza and bread. A separate heating element heats the solid stone from underneath to temperatures up to 550°F – creating a crispy base for baked goods. Now your pastries can rival the Danish; your pizza, the Neapolitans; and your baguette, the French.



Versatile and practical. The latest combi-steam ovens offer an enlarged cavity with which to master the culinary style. It not only steams, but braises, bakes, browns, grills, gratinates, regenerates, sous-vides and even extracts juice. After which, it cleans itself using its sophisticated automatic cleaning system and its own water supply.

TO COOK A PERFECT DISH, YOU NEED MORE THAN A GOOD RECIPE

Optimized cooking routines ease preparation and allow you to focus on your creative talents. Inspired by the streamlined workflow of a professional kitchen, Gaggenau has developed accessories that enhance the appliances and, in the end, a home chef's masterpiece. Let the artistry begin.



Exclusively for our in-home chefs. With different vacuum levels and sizes of bags, you will be able to lock in flavors, preserve ingredients and marinade in a third of the time. With the ability to vacuum outside of the drawer you can also enjoy opened wine even after the following night.

Single ovens

For use with 24" **BOP 250/251** and **BO 450/451** ovens

BA 016 165

Pull-out system
Enameled cast-iron frame and fully extendable telescopic rails, pyrolytic-safe.



BA 026 115

Baking tray
Enameled
7/16" deep.




BA 036 165

Wire rack
Chromium-plated
Offset rack, no opening, with feet.



BA 056 115

Heating element
Necessary accessory for baking stone BA 056 133 and GN 340 230 Gastronorm roaster.



BA 056 133

Baking stone
Includes support and pizza peel.



BS 020 002

Pizza peel
Additional set of 2.



GN 340 230

Gastronorm roaster
Non-stick cast-aluminum
4" deep, with 2 1/2" lid, GN 2/3.
Order GN 010 330 adapter for use with the combi-steam oven.



BA 226 105

Roasting pan
Enameled
1" deep.



BA 046 117

Glass tray
1" deep.
Can be used with 24"/30" BS combi-steam ovens.



For use with 30" **BO 480/481** ovens and **BX 480/481** double ovens and 36" **EB 333** oven

BA 018 165

Pull-out system
Enameled cast-iron frame and fully extendable telescopic rails, pyrolytic-safe.



BA 028 115

Baking tray
Enameled
1" deep.




BA 038 165

Wire rack
Chromium-plated
Offset rack, no opening, with feet.



BA 058 115

Heating element
Necessary accessory for baking stone BA 058 133 and GN 340 230 Gastronorm roaster.



BA 058 133

Baking stone
Includes support and pizza peel.



BS 020 002

Pizza peel
Additional set of 2.



GN 340 230

Gastronorm roaster
Non-stick cast-aluminum
4" deep, with 2 1/2" lid, GN 2/3.
Order GN 010 330 adapter for use with the combi-steam oven.



Part No. 17001373 ▼

Roasting pan
Enameled
With feet and rotisserie spit attachment, 1" deep.



BA 090 100

Stainless steel knobs
With black coating
Set of 2.
For use with the EB 333.



Combi-steam ovens

For use with 24" **BS 470/471 612**, **BS 474/475 612** and 30" **BS 484/485 612** Combi-steam ovens

GN 114 230

Gastronorm pan, unperforated
Stainless steel
1½" deep, GN 2/3 full tray size.
Order GN 010 330 adapter for use
with the Combi-steam oven.




GN 124 230

Gastronorm pan, perforated
Stainless steel
1½" deep, GN 2/3 full tray size.
Order GN 010 330 adapter for use
with the Combi-steam oven.



BA 010 301

Triple telescopic pull-out rack



BA 020 361

Cooking container, stainless steel,
unperforated, 1 9/16" (46 mm) deep, 5 qt.
Cannot be used on lower level of
appliances produced before December
2022. Order glass tray BA 046 117 instead.



BA 020 370

Cooking container, stainless steel,
perforated, 1 9/16" (40 mm) deep, 5 qt.




BA 020 381

Cooking container, non-stick,
unperforated, 1 9/16" (46 mm) deep, 5 qt.
Cannot be used on lower level of
appliances produced before December
2022. Order glass tray BA 046 117 instead.




BA 020 390

Cooking container, non-stick,
perforated, 1 9/16" (40 mm) deep, 5 qt.



GN 010 330

Adapter for gastronorm insert and
roaster.



BA 046 117

Glass tray
1" deep.
Can also be used with 24" BO and
BOP ovens.



GN 340 230

Gastronorm roaster
Non-stick cast-aluminum
4" deep, with 2 ½" lid, GN 2/3.
Order GN 010 330 adapter for use
with the combi-steam oven.



GN 114 130

Gastronorm pan, unperforated
Stainless steel
1½" deep, GN 1/3 half tray size.
Order GN 010 330 adapter for use
with the combi-steam oven.



GN 124 130

Gastronorm pan, perforated
Stainless steel
1½" deep, GN 1/3 half tray size.
Order GN 010 330 adapter for use
with the combi-steam oven.



CL S10 040

Cleaning cartridges, set of 4



Part No. 17002490

Descaling tablets, set of 4.



Part No. 00578813

Vacuuming bags, large
9 7/16" x 13 15/32", 100 pcs.
For use with the vacuuming drawers
DV 461/463.



Part No. 00578814

Vacuuming bags, small
7 3/32" x 1 11/32", 100 pcs.
For use with the vacuuming drawers
DV 461/463.



ACCESSORIES

Cooktops

For use with **Vario cooktops**

WP 400 001

Wok pan
Multiple-layered material
With round bottom and handle
ø 14 ³/₁₆", 5.3 quarts, height 3 ¹⁵/₁₆".
For use with 400 series VI 414 induction wok and VI 492 cooktops.



WZ 400 000

Wok support ring for wok pan
Necessary for use with 400 series
VI 414 induction wok and VI 492 cooktop.



LV 030 000

Lava Rock
Lava stones for refilling
For use with the VR 414 and VR 230.



AA 414 010

Air Deflector
For VL 414 next to gas appliance.



For use with **induction** and **flex induction cooktops**

CA 051 301

Teppan Yaki made of multi ply material,
16" x 10".
For use with CI 282/292 flex induction,
CX 482/492 (including Teppanyaki mode),
VI 422 and VI 492 cooktops.
(Available from September 2024)



GN 232 110

Teppan Yaki
Multi-ply material
13" x 21", GN ¹/₄.
For use with CX 482/492
(including Teppanyaki mode).



CA 230 100

Stainless steel knob
With black coating
For CI 282/292 flex induction cooktops.



CA 060 600

Cooking sensor for temperature
regulation with pots.
For use with CX 482/492 and
CI 282/292 flex induction cooktops.



For use with **gas cooktops**

WP 400 001

Wok pan
Multiple-layered material
With round bottom and handle
ø 14 ³/₁₆", 5.3 quarts, height 3 ¹⁵/₁₆".
For use on center wok burner of VG 295,
VG 491 gas cooktops, VG 231 gas
cooktop and VG 415.




Refrigeration

For use with 18" wine storage unit **RW 414**

RA 492 160

Removable shelf with oak wood frame.
Suitable for decanters and open bottles.




RA 493 060

Presenter in oak wood and aluminum in anthracite for single bottle display.
1 piece.



RA 491 161

Fully extendable bottle trays with hidden telescopic rails in oak wood and solid aluminum in anthracite.



RA 498 140

Bottle support in oak wood for convenient storage of bottles on the division plate.



RA 430 000


Screw hole cover set. 8 pieces.



For use with 24" wine storage unit **RW 466**

RA 492 660

Removable shelf with oak wood frame.
Suitable for decanters and open bottles.




RA 493 060

Presenter in oak wood and aluminum in anthracite for single bottle display.
1 piece.



RA 491 661

Fully extendable bottle trays with hidden telescopic rails in oak wood and solid aluminum in anthracite.



RA 498 640

Bottle support in oak wood for convenient storage of bottles on the division plate.



RA 430 000

Screw hole cover set. 8 pieces.



For use with refrigerators **RC 462/472/492, RVB 477/497** and **RVY 497**

RA 430 100

Storage container with transparent lid, anthracite.
To add the egg insert, please order Part #11031964 in addition to the container.



RVA 438 040

Bottle support in oak wood with magnetic connector



Part #11037377

Water filter bypass for home water filtration system.



Part #17006999

Ethylene absorber.
For placement in a fresh cooling drawer.



Part #17007000

Ethylene absorber refill kit.
For placement in a fresh cooling drawer.



RA 450 022

Activated charcoal water filter
For RVY, RVB and RF.



Dishwashers

DA 042 030

Sterling silver cutlery cassette.
Aluminum silver care cassette to protect corrosion of silver cutlery.
Easy placement of cartridge in the cutlery basket.
W x H x D in inches: 2 1/16" x 8 9/16" x 1 7/8".



DA 043 000

Holder for long-stemmed glasses.
Offers safe positioning for up to four longstemmed glasses during the wash cycle and ensures optimal cleaning results. For positioning in the lower rack.



DA 045 060

3rd basket.
3rd loading level above the upper basket.
For small bowls, cups and cooking utensils.
Movable knife shelf.
Only for use with DF 211 dishwasher.



DA 045 061

3rd basket.
With smooth running rails.
3rd loading level above the upper basket.
For small bowls, cups and cooking utensils.
Movable knife shelf.
Only for use with DF 481/DF 481F dishwasher.



The difference is Gaggenau



Gaggenauofficial



gaggenau_



showcase/gaggenau/



gaggenauofficial

gaggenau.com